

ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS














- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast and easy assembly.




Warning !


- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.




HARDWARE LIST			
1	 JCBC M6 x 60mm 4 PCS	8	 HEX NUT 8 PCS
2	 JCBC M6 x 35mm 4 PCS	9	 H/M WASHER 8 PCS
3	 JCBC-W M6 x 30mm 8 PCS	10	 MINIFIX CAM 20 PCS
4	 WOOD SCREW 4.0 x 30mm 30 PCS	11	 MINIFIX BOLT 20 PCS
5	 BARREL NUT M6 x 13mm 30 PCS	12	 ALLEN KEY M4 1 PC
6	 WOOD DOWEL Ø10 x 30mm 34 PCS	13	 SPANNER M8 1 PC
7	 HANGER BOLT 8 PCS		

COMPONENT LIST			
A	1 PC	G	2 PC
		LADDER STRETCHER	
			1 PC
		H	
B	1 PC	I	1 PC
HEADBOARD		RIGHT LADDER RAIL	
		J	1 PC
		LEFT LADDER RAIL	
C	2 PCS		
FOOTBOARD		SLAT	
D	2 PCS		
LEG - LEFT REAR & RIGHT FRONT			
E	2 PCS		
LEG - LEFT FRONT & RIGHT REAR			
F	2 PCS		
SIDE PANEL			
G			
SUPPORT RAIL			


STEP 1




STEP 2




STEP 3




STEP 4




STEP 5



STEP 6



STEP 7



STEP 8

